

## Snow Ice Shaver

### PDOM-GRM-NSF Trouble Shooting

Follow the instruction manual for trouble shooting.

If you are still having a problem, take a short video and send it to us at [service@bubbleteaology.com](mailto:service@bubbleteaology.com)


#### No Power -

1. Check if the circuit breaker button is pressed down. If not, press it and retry.



2. If that does not work, unplug your machine and try it in a different outlet (do not use an extension cord or a power supply).

3) If there still isn't any power, unplug the machine and open the top cover of the machine.



Remove the cover and take a picture for us to diagnose the problem.

**Follow the instruction manual for trouble shooting.**

**If you are still having a problem, take a short video and send it to us at [service@bubbleteaology.com](mailto:service@bubbleteaology.com)**